

# Numerical time integration methods for nonsmooth systems.

## Part I. Low relative degree and electrical networks applications

Vincent Acary  
INRIA Rhône-Alpes, Grenoble.

SDS2010. Capitolo, Monopoli, Italy. June 8–11, 2010.

[vincent.acary@inrialpes.fr](mailto:vincent.acary@inrialpes.fr)

Joint work with Olivier Bonnefon & Bernard Brogliato

Introduction & Motivations

Outline

Mathematical nature of the  
solutions

Numerical time-integration

Open issues

References

# The RLC circuit with a diode

## Example

A LC oscillator supplying a load resistor through a half-wave rectifier (see figure 1).




Figure: Electrical oscillator with half-wave rectifier

Numerical time integration methods for nonsmooth systems.

Part I. Low relative degree and electrical networks applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

[Introduction & Motivations](#)

[Outline](#)

[Mathematical nature of the solutions](#)


[Numerical time-integration](#)

[Open issues](#)


[References](#)

# The RLC circuit with a diode


## Example



(a) state versus time  $v_L$  and  $i_L$



(b) Diode current  $i_D$



(c) Diode voltage  $v_D$

Numerical time integration methods for nonsmooth systems.

Part I. Low relative degree and electrical networks applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

Introduction & Motivations

Outline

Mathematical nature of the solutions

Numerical time-integration

Open issues

References

# The RLC circuit with a diode

Numerical time integration  
methods for nonsmooth  
systems.

Part I. Low relative degree  
and electrical networks  
applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

## Example

- ▶ Kirchhoff laws :

$$\begin{aligned}v_L &= v_C \\v_R + v_D &= v_C \\i_C + i_L + i_R &= 0 \\i_R &= i_D\end{aligned}$$

- ▶ Branch constitutive equations for linear devices are :

$$\begin{aligned}i_C &= C\dot{v}_C \\v_L &= L\dot{i}_L \\v_R &= Ri_R\end{aligned}$$

- ▶ "branch constitutive equation" of the diode

$$0 \in \mathcal{F}(i_D, v_D)$$

Introduction & Motivations

Outline

Mathematical nature of the  
solutions

Numerical time-integration

Open issues

References

# The RLC circuit with a diode

## Example

The following dynamical system is obtained :

$$\begin{pmatrix} \dot{v}_L \\ \dot{i}_L \end{pmatrix} = \begin{pmatrix} 0 & \frac{-1}{C} \\ \frac{1}{L} & 0 \end{pmatrix} \cdot \begin{pmatrix} v_L \\ i_L \end{pmatrix} + \begin{pmatrix} \frac{-1}{C} \\ 0 \end{pmatrix} \cdot i_D$$

$$v_D = v_L - Ri_D$$

$$0 \in \mathcal{F}(v_D, i_D)$$


with the state variable  $x \triangleq \begin{pmatrix} v_L \\ i_L \end{pmatrix}$  and  $\lambda \triangleq i_D$ ,  $y \triangleq v_D$ , we get

$$\begin{cases} \dot{x} = Ax + B\lambda, & x \in \mathbb{R}^n, \lambda \in \mathbb{R}^m \\ y = Cx + D\lambda \\ 0 \in \mathcal{F}(y, \lambda) \end{cases} \quad (1)$$

# Diode behavior

## A modeling choice


smooth modeling



(a)

$$i(t) = i_s \exp\left(-\frac{v(t)}{\alpha} - 1\right)$$

nonsmooth modeling



(b)

$$0 \leq i(t) + b \perp v(t) + a \geq 0$$

Figure: Two models of diodes.

Numerical time integration methods for nonsmooth systems.

Part I. Low relative degree and electrical networks applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

Introduction & Motivations

Outline

Mathematical nature of the solutions

Numerical time-integration

Open issues

References

## Why a nonsmooth modeling ?

- ▶ To avoid stiff nonlinear models by using ideal constraints.
- ▶ To model the ideal behavior of switched components without artificial regularization

# The diode-bridge rectifier




Figure: The Diode-bridge rectifier

Numerical time integration methods for nonsmooth systems.

Part I. Low relative degree and electrical networks applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

Introduction & Motivations

Outline

Mathematical nature of the solutions

Numerical time-integration

Open issues

References



# The diode-bridge rectifier

Numerical time integration  
methods for nonsmooth  
systems.

Part I. Low relative degree  
and electrical networks  
applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

[Introduction & Motivations](#)

[Outline](#)

[Mathematical nature of the  
solutions](#)

[Numerical time-integration](#)

[Open issues](#)

[References](#)




Figure: The Diode-bridge rectifier. Standard results

# The diode-bridge rectifier

## Differential systems

The dynamical equations are formulated as

$$\begin{cases} \dot{x} = Ax + B\lambda, & x \in \mathbb{R}^n, \lambda \in \mathbb{R}^m \\ y = Cx + D\lambda \\ 0 \leq y \perp \lambda \geq 0 \end{cases} \quad (2)$$

choosing :

$$x = \begin{bmatrix} V_L \\ I_L \end{bmatrix}, \quad \text{and } y = \begin{bmatrix} I_{DR1} \\ I_{DF2} \\ V_2 - V_1 \\ V_1 - V_3 \end{bmatrix}, \quad \lambda = \begin{bmatrix} V_2 \\ -V_3 \\ I_{DF1} \\ I_{DR2} \end{bmatrix}, \quad (3)$$

and with

$$A = \begin{bmatrix} 0 & -1/C \\ 1/L & 0 \end{bmatrix}, \quad B = \begin{bmatrix} 0 & -1/C & 1/C & 0 \\ 0 & 0 & 0 & 0 \end{bmatrix}$$
$$C = \begin{bmatrix} 0 & 0 \\ 0 & 0 \\ -1 & 0 \\ 1 & 0 \end{bmatrix}, \quad D = \begin{bmatrix} 1/R & 1/R & -1 & 0 \\ 1/R & 1/R & 0 & -1 \\ 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \end{bmatrix} \quad (4)$$

# A typical example of nonsmooth systems

Numerical time integration  
methods for nonsmooth  
systems.


Part I. Low relative degree  
and electrical networks  
applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

## Linear Complementarity Systems (LCS)

$$\begin{cases} \dot{x} = Ax + B\lambda, & x \in \mathbb{R}^n, \lambda \in \mathbb{R}^m \\ y = Cx + D\lambda \\ 0 \leq y \perp \lambda \geq 0 \end{cases} \quad (5)$$

with  $A \in \mathbb{R}^{n \times n}$ ,  $B \in \mathbb{R}^{n \times m}$   
 $C \in \mathbb{R}^{m \times n}$ ,  $D \in \mathbb{R}^{m \times m}$ , for  $m$  constraints.



Introduction & Motivations

Outline


Mathematical nature of the  
solutions

Numerical time-integration


Open issues

References


## Piecewise linear systems



Saturation



Relay



Relay with dead zone

# A slightly more general class of nonsmooth systems

## Differential inclusion into normal cones

$$\begin{cases} \dot{x} = Ax + B\lambda, & x \in \mathbb{R}^n, \lambda \in \mathbb{R}^m \\ y = Cx + D\lambda \\ -y \in N_K(\lambda) \end{cases} \quad (6)$$

where  $K$  is a convex set and  $N_K(\lambda)$  stands for the normal cone to  $K$  taken at  $\lambda$

## Usual examples for $K$

- ▶  $K = \mathbb{R}^m$ , then we obtain linear time invariant DAE

$$-y \in N_{\mathbb{R}^m}(\lambda) \iff y = 0, \quad \lambda \in \mathbb{R}^m \quad (7)$$

- ▶  $K = \mathbb{R}_+^m$ , then we obtain Linear Complementarity Systems (LCS)

$$-y \in N_{\mathbb{R}_+^m}(\lambda) \iff 0 \leq y \perp \lambda \geq 0 \quad (8)$$

- ▶  $K = [-1, 1]^m$ , then we obtain linear relay systems ( related to Filippov's DI and sliding mode control).

$$-y \in N_{[-1,1]^m}(\lambda) \iff \lambda \in \text{sgn}(y) \quad (9)$$

# Objectives of my talk

- ▶ Understand what can be the nature of the solutions (uniqueness, smoothness).
- ▶ How perform the numerical time–integration ?
- ▶ Open issues for the time–integration of large dynamical systems arising in electrical network applications.

Numerical time integration  
methods for nonsmooth  
systems.

Part I. Low relative degree  
and electrical networks  
applications

Vincent Acary  
INRIA Rhône–Alpes,  
Grenoble.

Introduction & Motivations

Outline

Mathematical nature of the  
solutions

Numerical time–integration

Open issues

References

## Introduction & Motivations

## Mathematical nature of the solutions

## Numerical time-integration

## Open issues

Introduction & Motivations

Outline

Mathematical nature of the  
solutions

Numerical time-integration

Open issues

References

# Dynamical Complementarity systems

Numerical time integration  
methods for nonsmooth  
systems.

Part I. Low relative degree  
and electrical networks  
applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

Introduction & Motivations

Outline

Mathematical nature of the  
solutions

Numerical time-integration

Open issues

References

## Definition (Linear Complementarity Systems (LCS))

A Linear Complementarity System (LCS) is defined by

$$\begin{cases} \dot{x} = Ax + B\lambda \\ y = Cx + D\lambda \\ 0 \leq y \perp \lambda \geq 0 \end{cases} \quad (10)$$

for the quadruplet  $(A, B, C, D) \in \mathbb{R}^{n \times n} \times \mathbb{R}^{n \times 1} \times \mathbb{R}^{m \times n} \times \mathbb{R}^{m \times m}$ .

# The notion of relative degree. Well-posedness

Numerical time integration  
methods for nonsmooth  
systems.

Part I. Low relative degree  
and electrical networks  
applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

## Definition (Relative degree in the SISO case ( $m = 1$ ))

Let us consider a linear system in state representation given by the quadruplet  $(A, B, C, D) \in \mathbb{R}^{n \times n} \times \mathbb{R}^{n \times 1} \times \mathbb{R}^{m \times n} \times \mathbb{R}$ :

$$\begin{cases} \dot{x} = Ax + B\lambda \\ y = Cx + D\lambda \end{cases} \quad (11)$$

In the Single Input/ Single Output (SISO) case ( $m = 1$ ), the relative degree  $r$  is defined by the first non zero Markov parameter :

$$D, CB, CAB, CA^2B, \dots, CA^{r-1}B, \dots \quad (12)$$

Introduction & Motivations

Outline

Mathematical nature of the  
solutions

Numerical time-integration

Open issues

References



# The notion of relative degree. Well-posedness

Numerical time integration  
methods for nonsmooth  
systems.

Part I. Low relative degree  
and electrical networks  
applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

Introduction & Motivations

Outline

Mathematical nature of the  
solutions

Numerical time-integration

Open issues

References

## Definition (Uniform relative degree in the MIMO case ( $m > 1$ ))

Let us consider a linear system in state representation given by the quadruplet  $(A, B, C, D) \in \mathbb{R}^{n \times n} \times \mathbb{R}^{n \times m} \times \mathbb{R}^{m \times n} \times \mathbb{R}^{m \times m}$ :

$$\begin{cases} \dot{x} = Ax + B\lambda \\ y = Cx + D\lambda \end{cases} \quad (11)$$

In the multiple input/multiple output (MIMO) case ( $m > 1$ ), an *uniform* relative degree is defined as follows:

- ▶ If  $D$  is non singular, the relative degree is equal to 0.
- ▶ If  $D = 0$ , it is assumed to be the first positive integer  $r$  such that

$$CA^i B = 0, \quad i = 0 \dots r - 2 \quad (12)$$

while

$$CA^{r-1} B \text{ is non singular.} \quad (13)$$

- ▶ Other cases yield a nonuniform relative degree.

# The notion of relative degree. Well-posedness

Numerical time integration  
methods for nonsmooth  
systems.

Part I. Low relative degree  
and electrical networks  
applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

## Interpretation with the Markov parameters

The Markov parameters arise naturally when we derive with respect to time the output  $y$ ,

$$y = Cx + D\lambda$$

$$\dot{y} = CAx + CB\lambda, \text{ if } D = 0$$

$$\ddot{y} = CA^2x + CAB\lambda, \text{ if } D = 0, CB = 0$$

...

$$y^{(r)} = CA^r x + CA^{r-1} B \lambda, \text{ if } D = 0, CB = 0, CA^{r-2} B = 0, r = 1 \dots r - 2$$

...

and the first non zero Markov parameter allows us to define the output  $y$  directly in terms of the input  $\lambda$ .

Introduction & Motivations

Outline

Mathematical nature of the  
solutions

Numerical time-integration

Open issues

References

# The notion of relative degree. Well-posedness

Numerical time integration  
methods for nonsmooth  
systems.

Part I. Low relative degree  
and electrical networks  
applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

## Interpretation in terms of differential index of DAE

Let us consider the differential index  $\nu$  of the following linear time-invariant DAE

$$\begin{cases} \dot{x} = Ax + B\lambda \\ y = Cx + D\lambda \\ y = 0 \end{cases} \quad (11)$$

If the uniform relative degree of the quadruplet  $(A, B, C, D)$  is  $r$ , then the differential index  $\nu = r + 1$ .

Introduction & Motivations

Outline

Mathematical nature of the  
solutions

Numerical time-integration

Open issues

References

## Example (Third relative degree LCS)

$$\begin{cases} \ddot{x}(t) = \lambda(t) - 1, \\ y(t) = x(t) \\ 0 \leq y(t) \perp \lambda(t) \geq 0 \end{cases} \quad (12)$$

with the initial conditions,  $x(0) = x_0 \geq 0, \dot{x}(t_0) = \dot{x}_0, \ddot{x}(t_0) = \ddot{x}_0$ .

- ▶ the relative degree  $r$  is obviously 3, since  $y^{(3)} = \ddot{x} = \lambda - 1$
- ▶ since  $x_0 \geq 0$  satisfies the constraint, the function  $x : [0, T] \rightarrow \mathbb{R}$  is usually assumed to be an absolutely continuous function of time.

# The notion of relative degree. Well-posedness

## Example (Third relative degree LCS)

Let us consider the dynamics at  $t_*$  when the constraint  $y = x \geq 0$  becomes active, i.e.,  $x(t_*) = 0$ ,

- ▶ If  $\dot{x}(t_*^-) > 0$ , the system will instantaneously leaves the constraints with  $\dot{x}(t_*^+) = \dot{x}(t_*^-) > 0$ .
- ▶ If  $\dot{x}(t_*^-) < 0$ , the velocity  $\dot{x}$  needs to jump to respect the constraint in  $t_*^+$ . (B.V. function)
- ▶ If  $\dot{x}(t_*^-) < 0, \ddot{x}(t_*^-) < 0$ , the velocity and the acceleration need to jump to respect the constraint in  $t_*^+$ . (Dirac + B.V. function)

→ In the latter case,  $\ddot{x}$  and  $\lambda$  must be considered as derivative of Dirac distribution.

## Well-posedness for $r \geq 1$

What is the meaning of  $\lambda \geq 0$  when  $\lambda = \delta^{(r-1)}$

- ▶ If the initial conditions do not satisfy the constraints, the relative degree  $r \geq 1$  needs a rigorous definition of the sign of a distribution. (see [Acary et al., 2008] for details)

→ In this talk, we will focus on LCS of relative degree  $r \leq 1$ . The passive linear systems are of relative degree  $\geq 1$  [Camlibel, 2001, Heemels and Brogliato, 2003]).

# The notion of relative degree. Well-posedness

Numerical time integration  
methods for nonsmooth  
systems.

Part I. Low relative degree  
and electrical networks  
applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

Example (The relative degree not sufficient [Heemels and Brogliato, 2003])

Let us consider the following LCS

$$\begin{cases} \dot{x} = -x + \lambda \\ y = x - \lambda \\ 0 \leq y \perp \lambda \geq 0 \end{cases} \quad (12)$$

This system is strictly equivalent to

$$\dot{x} = \begin{cases} -x, & \text{if } x \geq 0 \\ 0, & \text{if } x < 0 \end{cases} \quad (13)$$

which leads to non existence of solutions for  $x(0) < 0$  and to non uniqueness for  $x(0) > 0$ .

Introduction & Motivations

Outline

Mathematical nature of the  
solutions

Numerical time-integration

Open issues

References

## Possible further assumptions for existence and uniqueness

- ▶ The Rational Complementarity problem [Heemels, 1999, Camlibel, 2001, Camlibel et al., 2002]. The P-matrix property plays henceforth a fundamental role and provides the existence of global solution of the LCS in the sense of Caratheodory.
- ▶ For the relative degree  $r = 1$  case,  $\exists P > 0$ , such that  $PB = C^T$ . A standard monotone differential inclusion is retrieved such that

$$- [\dot{z} + f(z, t)] \in A(z) \quad (12)$$

where  $A$  is a maximal monotone operator and  $f$  Lipschitz continuous.

→ Existence and uniqueness of a solution  $u \in C^0$  and  $\dot{u} \in L^\infty$ .

[Bastien and Schatzman, 2002]

# To summarize

## $C^1$ solutions

Mainly when  $B\lambda$  singleton

- ▶  $D$  positive definite (relative degree 0)
- ▶  $D$  is a P-matrix
- ▶  $D$  is a co-positive matrix

## Absolutely continuous solutions

- ▶ relative degree 1 with  $CB > 0$  or  $PB = C^T$  and  $P > 0$
- ▶ consistent initial conditions

## Solution of Bounded Variations

- ▶ relative degree 1 with  $CB > 0$  or  $PB = C^T$  and  $P > 0$
- ▶ inconsistent initial conditions

Numerical time integration  
methods for nonsmooth  
systems.

Part I. Low relative degree  
and electrical networks  
applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

Introduction & Motivations

Outline

Mathematical nature of the  
solutions

Numerical time-integration

Open issues

References



# Open issues of the well-posedness

Cases that are taken into account by the uniform relative degree (MIMO case)

For instance,  $D$  or  $CB$  singular but non zero

- ▶ Generalize the differential index ?

Assumption of positive definiteness of the Markov parameters.

- ▶ General assumption equivalent to  $B.SOL(Cx, D)$  for the relative degree 0.

Numerical time integration methods for nonsmooth systems.

Part I. Low relative degree and electrical networks applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

Introduction & Motivations

Outline

Mathematical nature of the solutions

Numerical time-integration

Open issues

References

## Introduction & Motivations

## Mathematical nature of the solutions

## Numerical time-integration

## Open issues

Introduction & Motivations

Outline

**Mathematical nature of the  
solutions**

Numerical time-integration

Open issues

References

# Targeted system

$$\dot{x} = Ax + u(t) + r$$

$$y = Cx + D\lambda + a(t)$$

$$R = B\lambda$$

$$0 \in y + N_{\mathbb{R}_+^m}(\lambda)$$

$$x(t_0) = x_0$$

] Differential Equations

] Input/output relations  
(nonsmooth components)

] Generalized equation

] Initial conditions

(13)

Numerical time integration  
methods for nonsmooth  
systems.

Part I. Low relative degree  
and electrical networks  
applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

Introduction & Motivations

Outline

Mathematical nature of the  
solutions

Numerical time-integration

Open issues

References

# Time-stepping schemes. Design principles.

Numerical time integration  
methods for nonsmooth  
systems.

Part I. Low relative degree  
and electrical networks  
applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

## First principle

The fully implicit evaluation of the generalized equation in (13), that is on  $[t_k, t_{k+1}]$ ,

$$0 \in y_{k+1} + N_{\mathbb{R}_+^m}(\lambda_{k+1}) \quad (14)$$

## Second principle

A consistent evaluation of the unknown variables and their derivatives according to their smoothness.

For instance, time-stepping schemes must not approximate high order time-derivatives of functions which are not sufficiently smooth or must not try to point-wisely evaluate distributions.

Introduction & Motivations

Outline

Mathematical nature of the  
solutions

Numerical time-integration

Open issues

References

# Time-stepping schemes for a solution for class $C^1$

Numerical time integration  
methods for nonsmooth  
systems.

Part I. Low relative degree  
and electrical networks  
applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

## Required assumptions

- ▶  $B\lambda$  Lipschitz continuous function of  $x$ .
- ▶ In particular,

$$0 \in Cx + D\lambda + a + N_K(\lambda) \quad (15)$$

possesses a unique solution for all  $x$ .

Introduction & Motivations

Outline

Mathematical nature of the  
solutions

Numerical time-integration

Open issues

References

## Proposed scheme

$$\left\{ \begin{array}{l} x_{k+1} - x_k = h(Ax_{k+\theta} + u_{k+\theta} + r_{k+\gamma}), \\ y_{k+1} = Cx_{k+1} + D\lambda_{k+1} + a_{k+1}, \\ r_{k+1} = B\lambda_{k+1}, \\ 0 \in y_{k+1} + N_K(\lambda_{k+1}), \end{array} \right. \quad (16)$$

with  $\theta \in [0, 1]$  and  $\gamma \in [0, 1]$ .  $x_{k+\theta} = (1 - \theta)x_k + \theta x_{k+1}$   
The initial value of  $\lambda_0 = \lambda(t_0)$  is given by the solution of (15).

# Time-stepping schemes for a solution for class $C^1$

Numerical time integration  
methods for nonsmooth  
systems.

Part I. Low relative degree  
and electrical networks  
applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

Introduction & Motivations

Outline

Mathematical nature of the  
solutions

**Numerical time-integration**

Open issues

References

## One-step LCP

$$\begin{cases} y_{k+1} = M\lambda_{k+1} + q \\ 0 \leq y_{k+1} \perp \lambda_{k+1} \geq 0, \end{cases} \quad (17)$$

with

$$M = D + h\gamma C(I - h\theta A)^{-1}B, \quad (18)$$

and

$$q = a_{k+1} + C(I - h\theta A)^{-1} [(I + h(1 - \theta)A)x_k + hu_{k+\theta} + h(1 - \gamma)B\lambda_k]. \quad (19)$$

# Time-stepping schemes for a solution for class $C^1$

Numerical time integration methods for nonsmooth systems.

Part I. Low relative degree and electrical networks applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

Introduction & Motivations


Outline

Mathematical nature of the solutions


Numerical time-integration

Open issues

References



(a) State  $x_1$  vs. time.



(b) Phase portrait.  $x_1$  vs.  $x_2$ .

**Figure:** Solution of the RLC circuit with the time-stepping scheme (16). (1) Exact solution  $x(t_k)$ . (2)  $x_k$  with  $\theta = 1, \gamma = 1$ . (3)  $x_k$  with  $\theta = 1/2, \gamma = 1$ . (4)  $x_k$  with  $\theta = 1/2, \gamma = 1/2$ .

## Influence of $\theta$ and $\gamma$

- ▶ Numerical parameters allows us to control numerical damping and order
- ▶ Second order accuracy can be achieved with  $\theta = \gamma = 1/2$ .
- ▶ Higher order approximations are useless and generate instabilities.

# Time-stepping schemes for an absolutely continuous solution

## Required assumptions

- ▶ Relative degree equal to 1 with consistent initial conditions

$$Cx_0 + a(t_0) \in \mathbb{R}_+^m. \quad (20)$$

and smooth function  $a(\cdot)$

- ▶ Monotony, positive definiteness, passivity assumption, . . . . .

## Proposed scheme

$$\begin{cases} x_{k+1} - x_k = h(Ax_{k+\theta} + u_{k+\theta} + r_{k+1}), \\ y_{k+1} = Cx_{k+1} + D\lambda_{k+1} + a_{k+1}, \\ r_{k+1} = B\lambda_{k+1}, \\ 0 \in y_{k+1} + N_K(\lambda_{k+1}), \end{cases} \quad (21)$$

with  $\theta \in [0, 1]$ .



# Time-stepping schemes for an absolutely continuous solution

Numerical time integration methods for nonsmooth systems.

Part I. Low relative degree and electrical networks applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

## Properties

- ▶ Order 1 is achieved for  $\theta \in [0, 1]$
- ▶  $\theta$  controls the numerical damping and the stability

## Why do not use $\gamma = 1/2$ ?

- ▶ No improvements for the order of accuracy
- ▶ Severe instabilities and numerical artifacts on  $r$  and  $\lambda$ .

With  $\gamma = 1/2$ , we attempt a second order approximation of a function of bounded variations  $\lambda$ .

Introduction & Motivations

Outline

Mathematical nature of the solutions

**Numerical time-integration**

Open issues

References

# Time-stepping schemes for solution of bounded variations

Numerical time integration  
methods for nonsmooth  
systems.

Part I. Low relative degree  
and electrical networks  
applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

## Required assumptions

- ▶ Relative degree equal to 1 with inconsistent initial conditions

$$Cx_0 + a(t_0) \notin \mathbb{R}_+^m. \quad (22)$$

and/or nonsmooth function  $a(\cdot)$ .

- ▶ Monotony, positive definiteness, passivity assumption, . . . . .
- ▶ Relative degree 2 with consistent initial conditions.

Introduction & Motivations

Outline

Mathematical nature of the  
solutions

**Numerical time-integration**

Open issues

References

# Time-stepping schemes for solution of bounded variations

Numerical time integration  
methods for nonsmooth  
systems.

Part I. Low relative degree  
and electrical networks  
applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

## Measure differential equations (in a nutshell)

$$dx = Ax(t)dt + u(t)dt + Bdi, \quad (23)$$

- ▶  $dx$  is the differential measure associated with the RCBV function  $\dot{x}(t)$  and  $di$  is also a measure
- ▶ The absolutely continuous function  $\lambda(t)$  is the Radon-Nikodym derivative of  $di$  with respect to the Lebesgue measure, *i.e.* :

$$\frac{di}{dt} = \lambda(t). \quad (24)$$

[Introduction & Motivations](#)

[Outline](#)

[Mathematical nature of the solutions](#)

[Numerical time-integration](#)

[Open issues](#)

[References](#)

## Measure decomposition

$$di = \lambda(t)dt + \sum_i \sigma_i \delta_{t_i} \quad (25)$$

where  $\delta_{t_i}$  is the Dirac measure at time of discontinuities  $t_i$  and  $\sigma_i$  the amplitude.

- ▶ Smooth dynamics :

$$\dot{x}(t) = Ax(t) + u(t) + B\lambda(t), \quad dt - \text{almost everywhere}, \quad (26)$$

- ▶ Jump dynamics at  $t_i$  :

$$x(t_i^+) - x(t_i^-) = B\sigma_i. \quad (27)$$

# Time-stepping schemes for solution of bounded variations

Numerical time integration  
methods for nonsmooth  
systems.

Part I. Low relative degree  
and electrical networks  
applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

## Design of a consistent scheme

Only the measure of the time-intervals  $(t_k, t_{k+1}]$  are considered such that :

$$dx((t_k, t_{k+1}]) = \int_{t_k}^{t_{k+1}} Ax(t) + u(t) dt + Bdi((t_k, t_{k+1}]). \quad (28)$$

By definition of the differential measure, we get

$$dx((t_k, t_{k+1}]) = x(t_{k+1}^+) - x(t_k^+). \quad (29)$$

The measure of the time-interval by  $di$  is kept as an unknown variable denoted by

$$\sigma_{k+1} = di((t_k, t_{k+1}]). \quad (30)$$

Finally, the remaining Lebesgue integral in (28) is approximated by an implicit Euler scheme

$$\int_{t_k}^{t_{k+1}} Ax(t) + u(t) dt \approx hAx_{k+1} + u_{k+1}. \quad (31)$$

[Introduction & Motivations](#)

[Outline](#)

[Mathematical nature of the  
solutions](#)

[Numerical time-integration](#)

[Open issues](#)

[References](#)

# Time-stepping schemes for solution of bounded variations

Numerical time integration  
methods for nonsmooth  
systems.

Part I. Low relative degree  
and electrical networks  
applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

## Proposed scheme

$$\left\{ \begin{array}{l} x_{k+1} - x_k = h(Ax_{k+1} + u_{k+1}) + \sigma_{k+1}, \\ y_{k+1} = Cx_{k+1} + a_{k+1}, \\ r_{k+1} = B\sigma_{k+1}, \\ 0 \in y_{k+1} + N_K(\sigma_{k+1}). \end{array} \right. \quad (32)$$

Introduction & Motivations

Outline

Mathematical nature of the  
solutions

Numerical time-integration

Open issues

References

## Properties

- ▶ At best order 1 is achieved. (no rigorous proof for a finite accumulation of jumps)
- ▶ Implicitly implements a restitution rule with “no rebounds”

# Time-stepping schemes for solution of bounded variations

## Example (An RLD circuit)




Figure: A circuit with an ideal diode, a resistor, an inductor and a current source.

$$\begin{cases} \dot{x}(t) = -\frac{R}{L}x(t) + v(t) \\ 0 \leq w(t) = x(t) - i(t) \perp v(t) \geq 0 \\ x(t^+) = i(t^+) + \max[0, x(t^-) - i(t^+)] \text{ at jump times,} \end{cases} \quad (33)$$

# Time-stepping schemes for solution of bounded variations

Numerical time integration methods for nonsmooth systems.

Part I. Low relative degree and electrical networks applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

Let us choose  $x(0^-) = -2$  and

$$i(t) = \begin{cases} 0 & \text{for all } t \in [0, 5) \\ 2 & \text{for all } t \in (5, 10) \\ -2 & \text{for all } t \geq 10 \end{cases}$$

The analytical solution with this value for the current source is:

$$x(t) = \begin{cases} x(0^+) = 0, & x(t) = 0, & v(t) = 0 & \text{on } t \in (0, 5) \\ x(5^+) = 2, & x(t) = 2, & v(t) = 2 & \text{on } t \in [5, 10) \\ x(10^+) = 2, & x(t) = 2e^{(10-t)} & v(t) = 0 & \text{on } t \in [10, +\infty). \end{cases} \quad (34)$$

[Introduction & Motivations](#)

[Outline](#)

[Mathematical nature of the solutions](#)

[Numerical time-integration](#)

[Open issues](#)

[References](#)



# Time-stepping schemes for solution of bounded variations

Numerical time integration methods for nonsmooth systems.

Part I. Low relative degree and electrical networks applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

Introduction & Motivations


Outline

Mathematical nature of the solutions


Numerical time-integration

Open issues


References




(a) state  $x_k$  vs  $t_k$



(b) output  $w_k$  vs  $t_k$



(c) variable  $\lambda_k$  vs  $t_k$



(d) variable  $\sigma_k$  vs  $t_k$

Figure: Simulation of system (33). (1) scheme (30). (2) scheme (21) with  $\theta = 1/2$ . (3) scheme (16) with  $\theta = 1/2, \gamma = 1/2$ .

## Introduction & Motivations

## Mathematical nature of the solutions

## Numerical time-integration

## Open issues

Introduction & Motivations

Outline

Mathematical nature of the  
solutions

**Numerical time-integration**

Open issues

References

# Applications to industrial electrical networks

Numerical time integration methods for nonsmooth systems.

Part I. Low relative degree and electrical networks applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

Introduction & Motivations

Outline

Mathematical nature of the solutions

Numerical time-integration

Open issues

References




Figure: Buck converter.

# Applications to industrial electrical networks

Numerical time integration methods for nonsmooth systems.

Part I. Low relative degree and electrical networks applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

Introduction & Motivations


Outline

Mathematical nature of the solutions


Numerical time-integration

Open issues


References




(a)  $V_{load}$



(b)  $I_L$



(c) pMOS drain potential



(d)  $V_{ramp}$  and  $V_{error}$

Figure: SICONOS buck converter simulation using standard parameters.

# Applications to industrial electrical networks

Numerical time integration methods for nonsmooth systems.

Part I. Low relative degree and electrical networks applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

Introduction & Motivations


Outline

Mathematical nature of the solutions


Numerical time-integration

Open issues

References



(a)  $V_{\text{comp}}$  and  $V_{\text{drain}}$



(b)  $V_{\text{ramp}}$  and  $V_{\text{error}}$

Figure: SICONOS buck converter simulation using sliding mode parameters.

For more general formulations and more complex systems, are we able to infer the nature of the solutions? That is to say,

- ▶ Define and predict an equivalent notion to index and relative degree for instance, for a matrix  $D$  semi-definite positive.
- ▶ Given passive components, are we able to forecast the nature of the solutions from some topological considerations ? (as for the DAE case.)
- ▶ Adapt the time-stepping schemes in an hierarchical way in taking into account the "index" of each variable.

## Introduction & Motivations

## Mathematical nature of the solutions

## Numerical time-integration

## Open issues

Introduction & Motivations

Outline

Mathematical nature of the  
solutions

Numerical time-integration

**Open issues**

References

Thank you for your attention.

Numerical time integration  
methods for nonsmooth  
systems.

Part I. Low relative degree  
and electrical networks  
applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

Introduction & Motivations

Outline

Mathematical nature of the  
solutions

Numerical time-integration

Open issues

References



- V. Acary, B. Brogliato, and D. Goeleven. Higher order Moreau's sweeping process: mathematical formulation and numerical simulation. *Mathematical Programming Ser. A*, 113(1):133–217, 2008.
- J. Bastien and M. Schatzman. Numerical precision for differential inclusions with uniqueness. *ESAIM M2AN: Mathematical Modelling and Numerical Analysis*, 36(3):427–460, 2002.
- M. K. Camlibel. *Complementarity Methods in the Analysis of Piecewise Linear Dynamical Systems*. PhD thesis, Katholieke Universiteit Brabant, 2001. ISBN: 90 5668 073X.
- M. K. Camlibel, W.P.M.H. Heemels, and J.M. Schumacher. Consistency of a time-stepping method for a class of piecewise-linear networks. *IEEE Trans. Circuits and systems I*, 49:349–357, 2002.
- W.P.M.H. Heemels. *Linear Complementarity Systems. A Study in Hybrid Dynamics*. PhD thesis, Technical University of Eindhoven, 1999. ISBN 90-386-1690-2.
- W.P.M.H. Heemels and B. Brogliato. The complementarity class of hybrid dynamical systems. *European Journal of Control*, 9:311–349, 2003.

Numerical time integration methods for nonsmooth systems.

Part I. Low relative degree and electrical networks applications

Vincent Acary  
INRIA Rhône-Alpes,  
Grenoble.

[Introduction & Motivations](#)

[Outline](#)

[Mathematical nature of the solutions](#)

[Numerical time-integration](#)

[Open issues](#)

[References](#)